

Best practices for a greener tomorrow

Follow these simple tips and maximize the efficiency of Your AC and your efforts to save the ecology.



Clean air filter periodically to enable the unit to cool down Faster,therby saving energy consumption.



Activate "sleep" features on AC to turn off automatically Instead of using it the whole night which saves power.



You can reduce air-conditioning energy use by as much as 40 Percent by shading your home's windows and walls. Plant tress And shrubs to keep the days hottest sun off your house,



For the purpose of recycling to facilitate effective utilization of resources, please return this product to a nearby authorized collection center / registered dismantler or recycler while disposing off this product.

In case of further assistance, you may contact nearest authorized service center.

Please see the Company website for more information & collection centers, etc. Visit-htpp://www.servicedelight.com





Committed to You. Committed to Nature

Committed to service, at Videocon, service commitment is of at most priority, which is why our dedication goes beyond the conventional for us, service is not just about keeping product at their operational best, but also the beginning of a binding relationship. with more than 350 customer care points spread across the country to address your needs, we are just a call away. Our end avour is to faster a bigger cause by keeping our product eco-fit.


VIDEOCON INDUSTRIES LIMITED

Reg. Office: Videocon Industries Itd.,14Km Stone, Aurangabad-Paithan Road, Chitegaon, Dist-Aurangabad-431 105 (India).Phone No: 02431-251501 FAX: 91-2431-251551 Corporate Office: Plot no.254, Udyog Vihar, Phase-4, Gurgaon-122015, Phone no: 0124-4215400 For more details visit is at www.videoconworld.com.for online shopping visit us at www.edigiworld.com You should write to us at marketing@vgmail.in. for service issues write to us at customercare@vgmail.in or **SMS SVC TO 53030**





OWNER / INSTRUCTION MANUAL



SPLIT AIRCONDITIONER

Please read this instruction manual carefully before operating Your machine. Retain it for future reference Record model name & serial number of the machine .please Quote this information when you require service.

Bring Home Innovation Bring Home Videocon

CONTENTS

North

45, Okhla Industrial Estate, Phase 3, New Delhi - 110 020. PHONE: 011 32711003/4/7/8/9.

South

3-6-430, 2nd Floor, Maithai Mansion, 4th Street Himayat Nagar, Hyderabad- 29. PHONE- 040 32566922 / 33

East

39C, Harish Mukherjee Road, Kolkata - 26. PHONE No. 033 44031400

West

Marol Bhavan, Marol Co op Ind. Area, M.V. Road, Andheri (E), Mumbai - 400 059.

Phone: 022 405 84600

Service Help Line:

39 40 40 40 (prefix STD code of the state capital)

E mail : Customercare@vgmail.in

SMS: SVC to 53030

SOCIABLE REMARK

When using this air conditioner in the European countries, please read the following information:

<u>DISPOSAL</u>: Do not dispose of this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

It is prohibited to dispose of this appliance in domestic household waste. For disposal, there are several possibilities:

- A) The municipality has established collection systems, where electronic waste can be disposed of at least free of charge to the user.
- B) When buying a new product, the retailer will take back the old product at least free of charge.
- C) The manufacturer will take back the old appliance for disposal at least free of charge to the user.
- As old products contain valuable resources, they can be sold to scrap metal dealers.

Wild disposal of waste in forests and landscapes endangers your health when hazardous substances leak into the ground-water and find their way into the food chain.





SERVICE CENTER COPY

Name of Customer:		Model:
Address:		Serial Number:
		Date of Purchase / Date of Installation:
		Installation Done By:
Contact Number:		Name of Service Center:
Installation		Commissioning:
1.Is the Capacity of the machine suitable for the room in which	Yes/No	10. Run the machine for 30minutes & check for the following. Yes/No.
machine is installed Room Dimensions:		a) Vibration / abnormal noise observation. Yes/No
Length- Width-		b) Electrical supply input VoltsV
Height-		i) Checked for earthing with the unitV If more than 3\
2. Is the strength of installation enough.	Yes/No	(Voltmeter reading must be less than 3V) please consult electrician for proper earthing
Is the machine installed securely on installation pla	te Yes/No	to the unit.
Direction of condenser of MOrth/South/East/West machine is towards		(V) (• •)
4. If the direction of the condenser is towards south Yes/No or west proper shade provided to the machine		li) Supply between L & E - 230± 10% V
		1) Supply Sourcest E & E 2502 1070
Specify piping length Horizontal & Vertical Distance between IDU & ODU	Hm Vm	iii) Supply between L & E - 230± 10%V
		c) Stabilizer Installed Yes/No If Yes Make: Output:\
6. Has the IDU been placed below ODU If yes, have U traps been provided at	Yes/No Yes/No	d) Current Drawin by the machineA Specify under test ru
every 5m.		e) Temperature Reading
7. Has gas charging been done for extra length of Piping	Yes/No	
To oxid longin or riping	Gms	Return Temperature C Difference should be more than 12 Degree C Difference C C
8. Installation of the Unit as per below distance spec. More than 'A' More than 10cm More than 10cm		Has the Indoor Unit been placed with slope towards drain end. If yes, mention angle of slope. Note: Water to be poured in drain Pan & proper draining from drain pipe to be checked.
More than 2.3m	More than 60cm	Customer Remarks / Signature: Service center stamp
Grade		Installer Sign

SAFETY PRECAUTIONS

To prevent injury to the user or other people and property damage, the following instructions must be followed. Incorrect operation due to ignoring of instructions may cause harm or damage. The seriousness is classified by the following indications.

A WARNING	This symbol indicates the possibility of death or serious injury.	\
▲ CAUTION	This symbol indicates the possibility of injury or damage to property.	_

Meanings of symbols used in this manual are as shown below.

\bigcirc	Never do this.
(!)	Always do this.

⚠ WARNING

OConnect with the power properly.

- Otherwise, it may cause electric
 It may cause electric shock or fire
 It may cause electric shock shock or fire due to excess heat generation
- ODo not modify power cord length or share the outlet
- It may cause electric shock or fire due to heat generation.
- Always ensure effective grounding.
- No grounding may cause electric shock.
- ODisconnect the power if strange sounds, smell, or
- It may cause fire and electric shock.
- OUse the correctly rated breaker or fuse.
- There is risk of fire or electric shock
- Ventilate room before operating air conditioner if there is a gas leakage
- It may cause explosion, fire and burns.

- ODo not operate or stop the unit by switching on or off
- due to heat generation.
- O Do not operate with wet hands or in damp
- It may cause electric shock.
- ODo not allow water to run into electric parts.
- It may cause failure of machine or electric shock.
- QDo not drink water drained from air conditioner.
- It contains contaminants and It may cause electric shock. could make you sick.
- O Do not use the power cord close to heating appliances.
- It may cause fire and electric shock.
 - O Do not use the power cord near flammable gas or combustibles, such as gasoline, benzene, thinner, etc

O Do not damage or use an

unspecified power cord.

O Do not direct airflow at

room occupants only.

This could damage your

breaker and a dedicated

No installation may cause

fire and electric shock.

Always install circuit

O Do not open the unit

during operation.

O Do not disassemble or

• It may cause failure and

modify unit.

electric shock

or fire.

health.

It may cause explosion or fire.

⚠ CAUTION

- ♥ When the air filter is to be removed, do not touch the metal parts of the unit.
- It may cause an injury.
- When the unit is to be cleaned, switch off, and turn off the circuit breaker.
- Do not clean unit when power is on as it may cause fire, electric shock or injury.
- O Stop operation and close the window in storm or hurricane.
- Operation with windows opened may cause wetting of indoor and soaking of household furniture.
- O Do not use strong detergent such as wax or thinner. Use a soft cloth for cleaning.
- Appearance may be deteriorated due to change of product color or scratching of its surface.
- O Do not place heavy object on the power cord and take care so that the cord is not compressed
- There is danger of fire or electric shock.

Do not clean the air conditioner with water.


 Water may enter the unit and degrade the insulation. It may cause an electric shock.

- O Do not put objects like thin rods into the panel of blower and suction side
- The high-speed fan inside may cause danger.
- O Do not put a pet or house plant where it will be exposed to direct air flow.
- This could injure the pet or plant.
- O Do not place obstacles around air-inlets or inside of air-outlet
- It may cause failure of appliance or accident.
- Ensure that the installation bracket of the outdoor appliance is not damage due to prolonged exposure.
- If bracket is damaged, there is concern of damage due to falling of unit.
- Use caution when unpacking and installing. Sharp edges could cause injury

- O Ventilate the room well when used together with a stove, etc.
- An oxygen shortage may occur.
- ODo not use for special purposes.
- Do not use this air conditioner to preserve precision devices, food, pets. plants, and art objects. It may cause deterioration
- O Turn off the main power switch when not using the unit for a long time
- It may cause failure of product or fire.
- Φ Alwavs insert the filters securely. Clean filter once every two weeks
- Operation without filters may cause failure.
- (n) If water enters the unit, turn the unit off and disconnect the power, contact a qualified service

OPERATING INSTRUCTIONS

Indoor unit



Indoor unit

- 1. Front panel
- 2. Air inlet
- 3. Air filter
- 4. Air outlet
- 5. Horizontal air flow grille
- 6. Vertical air flow louver(inside)
- Display panel

NOTE: The actual shape of the indoor unit you purchased may be slight different on front panel and display window.

Outdoor unit

- 8. Connecting pipe
- 9. Connecting cable
- 10. Stop valve

LED Display Window

NOTE:



ION indication lamp(optional function) This lamp illuminates when Clean Air feature is activated.

Indication lamp on LED Display window

DEFROST indication lamp (Enabled on cooling & heating models only): Lights up when the air conditioner starts defrosting automatically or when the warm air control feature is activated in heating

OPERATION indication lamp This lamp illuminates when the air conditioner is in operation.

TIMER indication lamp Lights up during Timer operation.

Temperature indicator

Displays the temperature settings when the air conditioner is operational.

Displays the malfunction code.

All the pictures in this manual are for explanation purpose only. Your air conditioner may be slightly different. The actual shape will prevail.



CUSTOMER COPY

Name of Customer:		Model:
Address:		Serial Number:
		Date of Purchase / Date of Installation:
		Installation Done By:
Contact Number:		Name of Service Center:
Installation		Commissioning:
1.Is the Capacity of the machine suitable for the room in which	Yes/No	10. Run the machine for 30minutes & check for the following.
machine is installed Room Dimensions:		a) Vibration / abnormal noise observation. Yes/No
Length- Width-		b) Electrical supply input VoltsV
Height-		i) Checked for earthing with the unitV If more than 3\
2. Is the strength of installation enough.	Yes/No	(Voltmeter reading must be less than 3V) please consult electrician for proper earthing
s the machine installed securely on installation pla	te Yes/No	to the unit.
Direction of condenser of NOrth/South/East/West machine is towards		$\left(\begin{array}{c} & & \\ & & \\ & & \end{array} \right)$
4. If the direction of the condenser is towards soon west proper shade provided to the machine	uth Yes/No	li) Supply between L & E - 230± 10%V
5. Specify piping length	m Hm Vm	iii) Supply between L & E - 230± 10%V
Horizontal & Vertical Distance between IDU & ODU		c) Stabilizer Installed Yes/No If Yes Make: Output: V
6. Has the IDU been placed below ODU	Yes/No	
If yes, have U traps been provided at every 5m.	Yes/No	d) Current Drawin by the machineA Specify under test rur
7. Has gas charging been done	Yes/No	e) Temperature Reading
for extra length of Piping -	Gms	Return Temperature C Difference should be Supply Temperature C more than 12 Degree C Difference C
8. Installation of the Unit as per below distance spec. More than 'A' More than 10cm More than 10cm		Has the Indoor Unit been placed with slope towards Yes/No drain end. If yes, mention angle of slope. Note: Water to be poured in drain Pan & proper draining from drain pipe to be checked.
More than 2.3m	More than 60cm	Customer Remarks / Signature: Service center stamp
Grade Clearance (cm) A B		

OPERATING INSTRUCTIONS

Special functions

Refrigerant Leakage Detection

With this new technology, the dipsplay area will appear 'EC' and the indication lamps continue flashing when the outdoor unit detects refrigerant leakage.

Louver Angle Memory Function(optional):

Within the scope of safety angle, it will memorize the open angle of horizontal louver. If it exceeds, it will memorize the boundry of safety angle. In the following circumstances, it will return to standard angle: 1) pressing the turbo or manual control button, 2)unplug and then plug in the machine. So we strongly suggest that the open angle of the horizontal louver should not be set too small, in case the condensed water forms and drops from the horizontal louver.

SELF CLEAN function Optional

For cooling models, the unit will operate under FAN ONLY mode at LOW fan speed for half an hour, and then turn off automatically.

For cooling & heating models, the unit will operate as in the below sequence:

FAN ONLY mode at Low fan speed--Heating operation with LOW fan speed

---FAN ONLY operation---Stop Operation----Turn off.

Note:

This function is only available under COOL(AUTO COOL, FORCED COOL) and DRY mode. Before selecting the function, it is recommended to run the air conditioner under cooling operation for about half an hour. Once the Self Clean function is activated, all TIMER setting will be cancelled.

CLEAN AIR function(on some models)

This air conditioner is equipped with ionizer or Plasma Dust Collector(Depending on specific configuration of the model). With the anions generated by Ionizer, the air circulation of the air conditioner fills the room with refreshing, natural and healthy air. The Plasma Dust Collector generates a high voltage ionization zone, through which the air is converted to plasma. Inside the air most of the dust, smoke, and pollen particles are captured by the electrostatic filter.

Anti-mildew function (Optional)

When turns off the unit on COOL, DRY, AUTO (Cool) mode, the air conditioner will continue operating for about 7-10 minutes (depending on models) with soft wind. This will help to dry up the condensed water inside the evaporator, and prevent the breeding of mildew. Under Anti-mildew operation, do not restart the air conditioner until the unit is completely off.

Vertical swing function (Optional)

After the AC starts up, users can control the vertical louver swing by the remote controller.



